

# Vanity with No Drawers

## Step-by-Step Assembly Instructions



Code	Item	Qty
A	RIGHT/LEFT SIDE PANEL	2
D	BOTTOM PANEL	1
H	BACK PANEL	1
J	TOE KICK PLATE	1
M	FRONT FACE	1
S	SUPPORT BRACKET	4

-Easy Assembly-  
**Metal Clip System**  
-Easy Assembly-



- ▶ Align clips **1** and **2**
- ▶ Slide **1** into **2**
- ▶ Insert locking screw into clip pair
- ▶ Tighten all screws

**Step 1**

- ▶ Lay H flat; grooves facing upward
- ▶ Insert A into metal clips of H (refer to Metal Clip System)

**Step 2**

- ▶ Slide D into grooves of A

**Step 3**

- ▶ Attach M onto D and A (refer to Metal Clip System)
- ▶ Attach J to bottom of A using the Metal Clip System

**Step 4**

- ▶ Place and screw S (plastic brackets) into corners of M, A, and H